

DeckHand 40 Remote Switch Accessory
Product# 1810150

25' Cord allows you to operate the DH40 from anywhere in your boat.
(optional accessory)

