



On the Vantage model the serial number is located on the front inside portion of the mounting bracket.