

HUMMINBIRD APEX™ SERIES

MODEL

APEX 19 MEGA SI+ CHARTPLOTTER
APEX 19 MEGA SI+ CHARTPLOTTER CHO

APEX 16 MEGA SI+ CHARTPLOTTER
APEX 16 MEGA SI+ CHARTPLOTTER CHO

APEX 13 MEGA SI+ CHARTPLOTTER
APEX 13 MEGA SI+ CHARTPLOTTER CHO

HUMMINBIRD SOLIX™ SERIES

MODEL

SOLIX 15 MEGA SI+ G3
SOLIX 15 MEGA SI+ G3 CHO
SOLIX 15 MEGA SI+ G2
SOLIX 15 MEGA DI+ G2 CHO
SOLIX 15 MEGA SI+
SOLIX 15

SOLIX 12 MEGA SI+ G3
SOLIX 12 MEGA SI+ G3 CHO
SOLIX 12 MEGA SI+ G2
SOLIX 12 MEGA DI+ G2 CHO
SOLIX 12 MEGA SI+
SOLIX 12

SOLIX 10 MEGA SI+ G3
SOLIX 10 MEGA SI+ G3 CHO
SOLIX 10 MEGA SI+ G2
SOLIX 10 MEGA DI+ G2 CHO
SOLIX 10 MEGA SI+
SOLIX 10

HUMMINBIRD HELIX™ SERIES

MODEL

HELIX 15 G4 SERIES

HELIX 15 CHIRP MEGA SI+ GPS G4N
HELIX 15 CHIRP MEGA DI+ GPS G4N (CHO)

HELIX 12 G4 SERIES

HELIX 12 CHIRP MEGA SI+ GPS G4N
HELIX 12 CHIRP MEGA DI+ GPS G4N
HELIX 12 CHIRP GPS G4N

HELIX 12 G3 SERIES

HELIX 12 CHIRP MEGA SI+ GPS G3N
HELIX 12 CHIRP MEGA DI+ GPS G3N
HELIX 12 CHIRP GPS G3N

HELIX 12 G2 SERIES

HELIX 12 CHIRP MEGA SI GPS G2N
HELIX 12 CHIRP MEGA DI GPS G2N
HELIX 12 CHIRP DI GPS G2N
HELIX 12 CHIRP GPS G2N

HELIX 12 G1 SERIES

HELIX 12 CHIRP SI GPS KVD
HELIX 12 CHIRP SI GPS
HELIX 12 CHIRP DI GPS
HELIX 12 CHIRP GPS

HELIX 10 G4 SERIES

HELIX 10 CHIRP MEGA SI+ GPS G4N
HELIX 10 CHIRP MEGA DI+ GPS G4N
HELIX 10 CHIRP GPS G4N

HELIX 10 G3 SERIES

HELIX 10 CHIRP MEGA SI+ GPS G3N
HELIX 10 CHIRP MEGA DI+ GPS G3N
HELIX 10 CHIRP GPS G3N

HELIX 10 G2 SERIES

HELIX 10 CHIRP MEGA SI GPS G2N
HELIX 10 CHIRP MEGA DI GPS G2N
HELIX 10 CHIRP DI GPS G2N
HELIX 10 CHIRP GPS G2N

HELIX 10 G1 SERIES

HELIX 10 SI GPS KVD
HELIX 10 SI GPS
HELIX 10 DI GPS
HELIX 10 SONAR GPS

HELIX 9 G4 SERIES

HELIX 9 CHIRP MEGA SI+ GPS G4N
HELIX 9 CHIRP MEGA DI+ GPS G4N
HELIX 9 CHIRP GPS G4N

HELIX 9 G3 SERIES

HELIX 9 CHIRP MEGA SI+ GPS G3N
HELIX 9 CHIRP MEGA DI+ GPS G3N
HELIX 9 CHIRP GPS G3N

HELIX 9 G2 SERIES

HELIX 9 CHIRP MEGA SI GPS G2N
HELIX 9 CHIRP MEGA DI GPS G2N
HELIX 9 CHIRP DI GPS G2N
HELIX 9 CHIRP GPS G2N

HELIX 9 G1 SERIES

HELIX 9 SI GPS KVD
HELIX 9 SI GPS
HELIX 9 DI GPS
HELIX 9 SONAR GPS

HELIX 8 G4 SERIES

HELIX 8 CHIRP MEGA SI+ GPS G4N
HELIX 8 CHIRP MEGA DI GPS G4N
HELIX 8 CHIRP GPS G4N

HELIX 8 G3 SERIES

HELIX 8 CHIRP MEGA SI+ GPS G3N
HELIX 8 CHIRP MEGA DI GPS G3N
HELIX 8 CHIRP GPS G3N

HELIX 7 G4 SERIES

HELIX 7 CHIRP MEGA SI GPS G4N
HELIX 7 CHIRP MEGA DI GPS G4N
HELIX 7 CHIRP MEGA DI GPS G4N (CHO)
HELIX 7 CHIRP GPS G4N
HELIX 7 CHIRP MEGA SI GPS G4
HELIX 7 CHIRP MEGA DI GPS G4
HELIX 7 CHIRP SI GPS G4

HELIX 7 G3 SERIES

HELIX 7 CHIRP MEGA SI GPS G3N
HELIX 7 CHIRP MEGA DI GPS G3N
HELIX 7 CHIRP GPS G3N
HELIX 7 CHIRP MEGA SI GPS G3
HELIX 7 CHIRP MEGA DI GPS G3
HELIX 7 CHIRP GPS G3

HELIX 7 G2 SERIES

HELIX 7 CHIRP SI GPS G2N
HELIX 7 CHIRP DI GPS G2N
HELIX 7 CHIRP GPS G2N
HELIX 7 CHIRP SI GPS G2
HELIX 7 CHIRP DI GPS G2
HELIX 7 CHIRP DI G2
HELIX 7 CHIRP GPS G2
HELIX 7 SONAR G2

HELIX 7 G1 SERIES

HELIX 7 SI GPS KVD
HELIX 7 SI GPS
HELIX 7 SONAR GPS
HELIX 7 SONAR

HELIX 5 G3 SERIES

HELIX 5 CHIRP DI GPS G3
HELIX 5 CHIRP GPS G3

HELIX 5 G2 SERIES

HELIX 5 CHIRP SI GPS G2
HELIX 5 CHIRP DI GPS G2
HELIX 5 CHIRP GPS G2
HELIX 5 SONAR G2

HELIX 5 G1 SERIES

HELIX 5 SI GPS KVD
HELIX 5 SI GPS
HELIX 5 SONAR GPS
HELIX 5 SONAR

HUMMINBIRD ONIX® SERIES**MODEL**

ONIX 10 ci SI NT combo
ONIX 10 ci NT combo
ONIX 10 ci SI Combo
ONIX 10ci Combo

ONIX 8 ci SI NT combo
ONIX 8 ci NT combo
ONIX 8 ci SI Combo
ONIX 8ci Combo

HUMMINBIRD 1100 SERIES

MODEL

1199ci HD SI Combo
1198c SI Combo
1159ci HD Combo
1158c Combo

HUMMINBIRD 900 SERIES

MODEL

999ci HD SI Combo KVD
999ci HD SI Combo
998c HD SI Combo
998c SI Combo
959ci HD Combo
958c HD Combo
958c Combo

HUMMINBIRD 800 SERIES

MODEL

899 ci HD SI Combo
898c HD SI Combo
898c SI Combo
859ci HD Combo
858c HD Combo
858c Combo

HUMMINBIRD 700 SERIES

MODEL

788ci HD Combo
778c HD
718

HUMMINBIRD 600 SERIES

MODEL

688 ci HD Combo
678c HD Combo
678c HD

HUMMINBIRD 500 SERIES

MODEL

597ci HD Combo
597ci Combo
596c HD Combo
587ci HD
586c HD
581i Combo
570
561
560

HUMMINBIRD 300 SERIES

MODEL

386ci Combo
385ci Combo
365i Combo
345c
325

HUMMINBIRD PiranhaMAX™ SERIES

MODEL

PiranhaMAX 155

LOWRANCE HOOK SERIES

MODEL

Hook 3x
Hook 4
Hook 5
Hook 7
Hook 9

LOWRANCE HOOK 2 SERIES

MODEL

Hook 2 4X*	
Hook 2 5X***	
Hook 2 5***	
Hook 2 7X***	
Hook 2 7***	
Hook 2 9***	
Hook 2 12***	
*Also requires Lowrance adapter cable part number 000-10000-0000	
***Can also use a MKR-US2-10 along with a Lowrance adapter cable	

LOWRANCE REVEAL SERIES

MODEL

Hook Reveal 5X***
Hook Reveal 5***
Hook Reveal 7X***
Hook Reveal 7***
Hook Reveal 9***
***Can also use a MKR-US2-10 along with a Lowrance adapter

LOWRANCE HDS SERIES

MODEL

HDS Carbon 7
HDS Carbon 9
HDS Carbon 12
HDS Carbon 16
HDS-16 Live*
HDS-12 Live*
HDS-9 Live*
HDS-7 Live*
HDS-12 Gen 3
HDS-12 Gen 2 Touch
HDS-12 Gen 2
HDS-12
HDS-10
HDS-9 Gen 3
HDS-9 Gen 2 Touch
HDS-9 Gen 2
HDS-9
HDS-8
HDS-7 Gen 3
HDS-7 Gen 2 Touch

HDS-7 Gen 2
HDS-7
HDS-5X
HDS-5
<u>*Can also use an MKR-US2-10 along with a Lowrance adapter c</u>

LOWRANCE ELITE SERIES

MODEL

Elite FS 7*
Elite FS 9*
Elite-7 Ti ² *
Elite-9 Ti ² *
Elite-12 Ti ² *
Elite-5 Ti*
Elite-7 Ti*
Elite-9 Ti*
Elite-12 Ti*
Elite-5X
Elite-5
Elite-4X
Elite-4
<u>*Can also use an MKR-US2-10 along with a Lowrance adapter c</u>

LOWRANCE MARK SERIES

MODEL

Mark-5X PRO
Mark-5X
Mark-4

LOWRANCE LCX SERIES

MODEL

LCX-113C
LCX-112C
LCX-111C
LCX-110C
LCX-38C
LCX-37C
LCX-28C
LCX-27C
LCX-26C
LCX-25C

LCX-17M
LCX-20C

LOWRANCE LMS SERIES

MODEL

LMS-527C
LMS-525C
LMS-522C
LMS-520C
LMS-480 DF
LMS-489
LMS-339C
LMS-337
LMS-335C DF
LMS-334C
LMS-332C
LMS-330C

LOWRANCE M SERIES

MODEL

M-68i
M-68C
M-56i
M-56
M-52i

LOWRANCE X SERIES

MODEL

X-515C
X-510C
X-136 DF
X-135
X-126 DF
X-125
X-107C DF
X-105C DF
X-102C
X-100C
X-59 DF
X-52
X-96

X-86DS
X-67C
X-50DS
X-47EX
X-47
X-4 Pro
X-4

GARMIN STRIKER™ SERIES

MODEL

Striker 4
Striker 4cv
Striker 5cv
Striker 7cv
Striker PLUS 4
Striker PLUS 4cv
Striker PLUS 5cv
Striker PLUS 7cv
Striker PLUS 7sv
Striker PLUS 9sv
Striker VIVID 4cv
Striker VIVID 5cv
Striker VIVID 7cv
Striker VIVID 7sv
Striker VIVID 9sv

GARMIN echoMAP™ SERIES

MODEL

echoMAP 94sv*
echoMAP 93sv*
echoMAP 74sv*
echoMAP 73sv*
echoMAP 74dv
echoMAP 73dv
echoMAP 70s
echoMAP 70dv
echoMAP 54dv
echoMAP 53dv
echoMAP 50s
echoMAP 50dv
echoMAP 44dv
echoMAP 43dv
echoMAP CHIRP 94sv*
echoMAP CHIRP 93sv*
echoMAP CHIRP 74sv*

echoMAP CHIRP 73sv*
echoMAP CHIRP 74cv
echoMAP CHIRP 73dv
echoMAP CHIRP 54cv
echoMAP CHIRP 53cv
echoMAP CHIRP 44cv
echoMAP CHIRP 43cv
echoMAP CHIRP 73cv
ECHOMAP Plus 43cv
ECHOMAP Plus 44cv
ECHOMAP Plus 63cv
ECHOMAP Plus 64cv
ECHOMAP Plus 73cv
ECHOMAP Plus 74cv
ECHOMAP Plus 73sv*
ECHOMAP Plus 74sv*
ECHOMAP Plus 93sv*
ECHOMAP Plus 94sv*
ECHOMAP UHD 43cv
ECHOMAP UHD 44cv
ECHOMAP UHD 63cv
ECHOMAP UHD 64cv
ECHOMAP UHD 73cv
ECHOMAP UHD 74cv
ECHOMAP UHD 73sv*
ECHOMAP UHD 74sv*
ECHOMAP UHD 93sv*
ECHOMAP UHD 94sv*
ECHOMAP Ultra 102/106sv*
ECHOMAP Ultra 122/126sv*
*also requires Garmin 8-pin Transducer to 12-pin Sounder Adapter Cable with XID

GARMIN GPSMAP® SERIES

MODEL

GPSmap 742/722xs Plus
GPSmap 942/922xs Plus
GPSmap 1242/1222xsv Plus *
GPSmap 743/723xsv *
GPSmap 943/923xsv *
GPSmap 1243/1223xsv *
GPSmap 8410/8610xsv *
GPSmap 8412/8612xsv *
GPSmap 8416/8616xsv *
GPSmap 1242xsv*
GPSmap 1222xsv*
GPSmap 1042xsv*

GPSmap 1022xsv*
GPSmap 1040xs
GPSmap 1020xs
GPSmap 942xs
GPSmap 922xs
GPSmap 840xs
GPSmap 820xs
GPSmap 7616xsv
GPSmap 7612xsv
GPSmap 7619xsv
GPSmap 7610xsv
GPSmap 7608xsv
GPSmap 7607xsv
GPSmap 742xs
GPSmap 722xs
GPSmap 741xs
GPSmap 721xs
GPSmap 527xs
GPSmap547xs
GPSMAP 536s
GPSMAP 535s
GPSMAP 531s
GPSMAP 530s
GPSMAP 431s
GPSMAP 430s
GPSMAP 198C
GPSMAP 188
GPSMAP 178C
GPSMAP 168
*also requires Garmin 8-pin Transducer to 12-pin Sounder Adapter Cable with XID

GARMIN echo™ SERIES

*requires Garmin 8-pin Transducer to 12-pin Sounder Adapter Cable with
MODEL
echo 551dv
echo 551c
echo 550
echo 501c
echo 500c
echo 301dv
echo 301c
echo 300c
echo 201dv
echo 201
echo 200
echo 151dv

echo 151
echo 150
echo 101
echo 100

GARMIN FISHFINDER SERIES

MODEL

Fishfinder 80‡
Fishfinder 90‡
Fishfinder 100‡
Fishfinder 120‡
Fishfinder 140‡
Fishfinder 160
Fishfinder 160C
Fishfinder 240
Fishfinder 250
Fishfinder 250C
Fishfinder 300C
Fishfinder 320C
Fishfinder 340C
Fishfinder 400C
‡Also requires Garmin power/data cable, part number 010-10000-00

EAGLE FishElite SERIES

MODEL

FishElite 642C
FishElite 640
FishElite 520C
FishElite 500C
FishElite 480
FishElite 320

EAGLE SeaCharter SERIES

MODEL

SeaCharter 500CDF
SeaCharter 480DF
SeaCharter 320DF

EAGLE FishMark SERIES

MODEL

FishMark 640C

FishMark 500C
FishMark 480
FishMark 320

EAGLE SeaFinder SERIES

MODEL

SeaFinder 642C
SeaFinder 640C
SeaFinder 500CD
SeaFinder 480DF
SeaFinder 320DF
SeaFinder 250DF
SeaFinder 245DS
SeaFinder 240DF

EAGLE FishEasy SERIES

MODEL

FishEasy 350C
FishEasy 320C
FishEasy 250DS
FishEasy 245DS
FishEasy 2

EAGLE CUDA SERIES

MODEL

Cuda 350
Cuda 300
Cuda 250
Cuda 242
Cuda 240i S/GPS
Cuda 240 S/GPS
Cuda 168EX
Cuda 168
Cuda 128

US2 CABLE**Item Number**

MKR-US2 13	1852073
MKR-US2 13	1852073

MKR-US2 13	1852073
MKR-US2 13	1852073

MKR-US2 13	1852073
MKR-US2 13	1852073

US2 CABLE**Item Number**

MKR-US2 13	1852073
MKR-US2 13	1852073
MKR-US2 13	1852073
MKR-US2 13	1852073
MKR-US2 13	1852073
MKR-US2 13	1852073

MKR-US2 13	1852073
MKR-US2 13	1852073
MKR-US2 13	1852073
MKR-US2 13	1852073
MKR-US2 13	1852073
MKR-US2 13	1852073

MKR-US2 13	1852073
MKR-US2 13	1852073
MKR-US2 13	1852073
MKR-US2 13	1852073
MKR-US2 13	1852073
MKR-US2 13	1852073

US2 CABLE**Item Number**

MKR-US2 8	1852068
MKR-US2 8	1852068

MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068

MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068

MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068

MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068

MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068

MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068

MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068

MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068

MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068

MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068

MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068

MKR-US2 8	1852068
MKR-US2 8	1852068

MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068

MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068

US2 CABLE

Item Number

MKR-US2 13	1852073
MKR-US2 13	1852073
MKR-US2 13	1852073
MKR-US2 13	1852073

MKR-US2 13	1852073
MKR-US2 13	1852073
MKR-US2 13	1852073
MKR-US2 13	1852073

US2 CABLE	Item Number
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068

US2 CABLE	Item Number
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068

US2 CABLE	Item Number
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068

US2 CABLE	Item Number
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068

US2 CABLE	Item Number
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068

US2 CABLE	Item Number
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068

US2 CABLE	Item Number
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068
MKR-US2 8	1852068

US2 CABLE	Item Number
MKR-US2 8	1852068

US2 CABLE	Item Number
MKR-US2-9	1852069
MKR-US2-10	1852060
MKR-US2-10	1852060
MKR-US2-10	1852060
MKR-US2-10	1852060

MKR-US2-9	1852069
MKR-US2-9	1852069
MKR-US2-9	1852069
MKR-US2-9	1852069
MKR-US2-9	1852069
MKR-US2-9	1852069
MKR-US2-9	1852069

US2 CABLE

Item Number

MKR-US2-12	1852072
MKR-US2-12	1852072
MKR-US2-12	1852072
MKR-US2-12	1852072
MKR-US2-12	1852072
MKR-US2-12	1852072
MKR-US2-12	1852072
MKR-US2-12	1852072
MKR-US2-12	1852072
MKR-US2-12	1852072
MKR-US2-12	1852072
MKR-US2-12	1852072
MKR-US2-12	1852072
MKR-US2-12	1852072
MKR-US2-12	1852072

US2 CABLE

Item Number

MKR-US2-14	1852074
MKR-US2-14	1852074
MKR-US2-14	1852074
MKR-US2-14	1852074
MKR-US2-12	1852072
MKR-US2-12	1852072
MKR-US2-14	1852074
MKR-US2-14	1852074
MKR-US2-12	1852072
MKR-US2-12	1852072
MKR-US2-14	1852074
MKR-US2-14	1852074
MKR-US2-12	1852072
MKR-US2-12	1852072
MKR-US2-14	1852074
MKR-US2-14	1852074
MKR-US2-14	1852074

- Garmin part number 010-12122-10, sold separately

US2 CABLE	Item Number
-----------	-------------

[illegible]

MKR-US2-12	1852072
MKR-US2-12	1852072
MKR-US2-12	1852072
MKR-US2-12	1852072

US2 CABLE	Item Number
MKR-US2-1	1852061
MKR-US2-1	1852061
MKR-US2-1	1852061
MKR-US2-1	1852061
MKR-US2-1	1852061
MKR-US2-1	1852061
MKR-US2-1	1852061
MKR-US2-1	1852061
MKR-US2-1	1852061
MKR-US2-1	1852061
MKR-US2-1	1852061
MKR-US2-1	1852061
MKR-US2-1	1852061
MKR-US2-1	1852061
0-10145-00, sold separately	

US2 CABLE	Item Number
MKR-US2-9	1852069
MKR-US2-9	1852069
MKR-US2-9	1852069
MKR-US2-9	1852069
MKR-US2-9	1852069
MKR-US2-9	1852069

US2 CABLE	Item Number
MKR-US2-9	1852069
MKR-US2-9	1852069
MKR-US2-9	1852069

US2 CABLE	Item Number
MKR-US2-9	1852069

