



Item	Part No.	Description	Item	Part No.	Description	Item	Part No.	Description
1	406-024	Front Endbell	34*A	225-4321	Arm- Lower (order item 34)	64	230-3120	Speed Nut (2 req'd)
3	406-404	Brush Plate Assembly	35	215-2610	Spring Pin	65	206-2550	Control Box
4	406-081	Brush Spring (2 req'd)	36	223-3600	Lock Bar	66	203-3400	Screw
5	406-072	Brush Assembly (2 req'd)	37	215-2700	Spring	67	201-3110	Hex Nut
6	406-341	Brush Plate Screw (2 req'd)	38	215-1700	Washer- Eye Shaft (4 req'd)	68	206-4022	Switch- 5 Spd, For/Rev
7	406-010	Ball Bearing	39	215-3600	Eye Shaft	71	299-0915	Handle Assembly
8	405-204	Armature Assembly	40	225-1600	Rope	72	206-0000	Handle Bearing (2 req'd)
9	405-300	E-Ring	41	215-0400	Pull Grip	77	230-2743	Spring- Detent
11	406-170	Thrust Washer- Steel (as req'd)	42	226-3900	Motor Rest	78	230-2742	Spring- Detent (Off)
12	406-171	Thrust Washer- Nylatron (as req'd)	43	230-3430	Screw (4 req'd)	79	206-0410	Handle- Top Half
13	406-480	Gasket	44	223-6000	Bearing- Nyliner (2 req'd)	80	206-0005	Bearing- Handle Pivot (2 req'd)
14	405-257	Center Section w/Magnets	45	229-3801	Tube Lock	81	206-0415	Handle- Lower Half
15	406-460	O-Ring	46	229-3511	Bolt- Upper Arm (4 req'd)	82	230-3720	Release Button
16	406-600	Flange Bearing	47	229-3500	Bushing (4 req'd)	83	230-2745	Spring- Release Button
17	406-032	Rear Endbell	48	223-0500	Hinge Pin (2 req'd)	84	230-3412	Screw (11 req'd)
18	406-461	Seal	49	225-1941	Bow Plate	85	206-0425	Handle- Extension
19	406-471	Seal- cup	50	226-7200	Latch Lever	87	203-1520	Collar- Depth
20	401-462	O-Ring- Thru Bolt (2 req'd)	51	226-0500	Pin- Roll Latch Lever (2 req'd)	88	201-1365	Knob Screw- Collar
21	405-352	Thru Bolt (2 req'd)	52	226-3800	Strap- Hold Down	89	203-0620	Leadwire- w/ Battery Clips
25	206-9020	Motor Assembly	53	226-1910	Bracket- Hold Down Strap	89A	201-0700	Replacement Battery Clips (2 req'd)
26	200-6606	Decal (2 req'd)	54	226-3440	Screw	90	201-0705	Battery Clip Sleeve- Black
27	203-2053	Tube	55	233-3101	Nut- Hex	90A	201-0706	Battery Clip Sleeve- Red
27	203-2054	Tube (48" Optional)	56	226-1811	Hinge Base	91	202-0310	Connector Cable
28	206-1125	Propeller	56*A	223-2350	Guide- Rope	92	299-4803	Bag Assembly (92A — 92D)
29	205-1700	Lockwasher	56*B	226-4705	Insert	92*A	215-3501	Mounting Bolt (4 req'd)
30	205-3100	Nut- Prop	57	233-1570	Sleeve- Roller	92*B	215-3100	Mounting Nut (4 req'd)
31	209-2600	Pin- Drive	58	226-1821	Hinge Door	92*C	215-1726	Flat Washer (4 req'd)
	299-1970	Bow Mount Assembly (32 — 60)	58A	215-1531	Hinge Sleeve Half (2 req'd)	92*D	230-1720	Mounting Washer- Rubber (6 req'd)
32	226-4201	Arm- Upper	59	226-2640	Hinge Pin- Door	93	225-6300	Tie Wrap
33	226-5120	Bumper	60	226-0180	Knob- Hinge Cover			
34	277-4302	Arm- Lower Assembly (34A — 41+ 59)	61	226-0210	Control Box Cover			
			62	218-5600	Decal- Cover			
			63	203-4033	Battery Gauge			

* This item is part of an assembly. This item cannot be sold separately due to machining and /or assembly that is required.
* Cet article fait partie d'un ensemble. Cet article ne peut être vendu séparément à cause d'un assemblage nécessaire.
* Este item faz parte de um conjunto. Este item não pode ser vendido separadamente devido a maquinamento e/ou montagem.

